




CHEMIN'ARTE


CHEMINÉES & RADIATEURS DESIGN DÉCORATIFS

Manual Instruction

Model Black River 103 and Empire State 104



1. LCD display
2. Power button
3. Date Time button
4. Timer Set button
5. Up button
6. + button
7. Clear button
8. Timer On/OFF button
9. - button



A.Heat button

B.Flame button

Manual Operation

STEP 1: Plug in and turn the mains power supply on.

STEP 2: Turn the on/off switch on the right hand side of the heater outlet to the “I” position.

STEP 3: Press the power button to turn on the appliance.

STEP 4: Press the “HEAT” button once to activate the low heat setting; press it again to activate the high setting, press it a third time to switch the heat setting off.

STEP 5: To change the flame brightness, press the "FLAME" button to cycle through the brightness options. Turn off the LED flame effect by pressing the "FLAME" button repeatedly until the flame effect cycles off.

STEP 6: Activate the standby mode by pressing the power button again.

STEP 7: Switch the fire off by turning the on/off switch on the right hand side of the heater to the “0” position.

Remote Control Operation

STEP 1: Switch on the appliance using the ON/OFF switch.

STEP 2: Press the power button on the remote control; the LCD display will illuminate.

STEP 3: Press “FLAME” button on the remote control to select the desired flame brightness; there are 3 different brightness levels available.

STEP 4: Select the desired heat output by pressing the relevant heat setting button:

To activate the low heat setting, press “HEAT I”; press it again to turn it off.

To activate the high heat setting, press “HEAT II”; press it again to turn it off.

AUTO Control Function

Press the "+" button on the remote control to increase the set temperature.

Press the "-" button to decrease the set temperature. The temperature can be set between 15-30°C.

Press "AUTO" to activate the automatic control function. The appliance will automatically activate / deactivate with the following functions:

If the room temperature is higher than the set temperature on the appliance, the heat will turn off.

If there is no operation for a few seconds, the remote control will show room temperature.

When AUTO mode is turned on, the HEAT I and HEAT II buttons are invalid.

Setting the Current Day and Time

The day and time can only be set using the remote control.

STEP 1: Press the "DATE TIME" button on the remote control, the day of the week will flash. Use the up and down buttons to set the day of the week. Once the current day is set, press the "DATE TIME" button to confirm the current day.

STEP 2: The hour setting will then flash once the day has been selected. Use "+" or "-" to adjust the time until the current hour is selected. Press the "DATE TIME" button to confirm the current hour.

STEP 3: Then the minute setting will flash once the hour has been set. Use "+" or "-" to adjust the time until the current minute is set correctly. Press the "DATE TIME" button to confirm the current minute.

Setting the Heat Timer

Press the "TIMER SET" button on the remote control, the time cycle number will flash. Use the "+" and "-" buttons to cycle through the different timer cycles from 1 to I0 and press the "TIMER SET" button to confirm. A small black triangle will flash below one day of the week, indicating that the day of the week need to be determined.

Press the "CLEAR" button can cancel the set time conveniently.

Selecting the Day

STEP 1: Press the up or down buttons on the remote control to choose the set day between "SUN" to "SAT", the default day is "SUN". Press the "+" button to confirm the set day. Press the "TIMER SET" button to confirm.

STEP 2: Repeat STEP 1 to add other days to the chosen timer cycle, or press the "-" button to delete the set day. Press the "TIMER SET" button to confirm.

Set TIMER ON Time

The "ON" symbol will illuminate on the LCD display to indicate that the Timer ON will need to be set.

STEP 1: Press the "+" or "-" button to set the hour setting for Timer ON and press the "TIMER SET" button to confirm.

STEP 2: Press the "+" or "-" button to set the minute setting for Timer ON and press the "TIMER SET" button to confirm. The "ON" symbol with turn off and the "OFF" symbol will illuminate.

Set TIMER OFF time

The "OFF" symbol will illuminate on the digital display to indicate that the Timer OFF will need to be set.

STEP 1: Press the "+" or "-" button to set the hour setting for Timer OFF and press the "TIMER SET" button to confirm.

STEP 2: Press the "+" or "-" button to set the minute setting for Timer OFF and press the "TIMER SET" button to confirm.

Setting The Desire Temperature

Once the Timer ON and OFF times have been set, the desired temperature will begin to flash on the digital display.

STEP 1: Press the "+" or "-" button to set the desired temperature between 15-30°C, PRESS "TIMER SET" BUTTON TO CONFIRM; the default temperature is 20°C.

STEP 2: Press the "AUTO" button and the "TIMER ON/OFF" button to activate the heat timer.

Note: Repeat the above procedure to set more timer cycles if required.

Press both "AUTO" button and "TIMER ON / OFF" button to activate the Timer Heat function.

Window Monitor Mode

When this function is enabled, if the ambient temperature is lowered due to the opening of the doors or windows, indicator light on “HEAT” button on the appliance will blink to remind the user to close the window / door. If there is no response, the system will automatically stop heating. Press the window button once to active the window monitor.

Press it again to switch the window monitor off.

PRODUCT SAFETY

When using any electrical appliance, basic safety precautions should always be followed including the following:

- Check that the voltage of the main circuit corresponds with the
- Switch off at the wall socket then remove the plug from the socket

rating of the appliance before operating.

- Please ensure that the appliance is used on a stable, level, and heat resistant surface.
- Do not immerse cords, plugs or any part of the appliance in water or any other liquid.
- Do not leave the appliance unattended while it is operating.
- Close supervision is necessary when any appliance is used by or near children.
- Take care when any appliance is used near pets.
- This appliance can be used by children aged from 8 years and above and person with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should not play with the appliance.
- Cleaning and user maintenance should not be undertaken by children without supervision.
- Always ensure that the heater is placed on a firm level surface. Ensure that the heater is not positioned close to curtains, furniture or any combustible materials as this could create a

when not in use or before cleaning.

- If the supply cord or appliance is damaged, stop using the appliance immediately and seek advice from the manufacturer, its service agent or a similarly qualified person.
- Do not let the cord hang over the edge of a table or counter or let it come into contact with any hot surfaces.
- The use of accessory attachments other than those supplied is not recommended.
- Do not pull the plug out by the cord as this may damage the plug and /or the cable.
- Do not use this product for anything other than its intended use.
- This appliance is for household use only.
- Do not carry the appliance by the power cord.
- Do not use any extension cord with this appliance.
- Do not use the appliance outdoors.
- This heater is not equipped with a device to control the room temperature. Do not use this heater in small rooms when they are occupied by persons not capable of leaving the room on their own, unless constant supervision is provided.

fire hazard.

- Never sit or stand on the fire.
- Never use this surround with a gas fire.
- Never stand or sit on the surround.

- Do NOT use the heater in areas where flammable liquids are stored or where flammable fumes may be present.
- Do NOT operate the heater on a timer, or leave on overnight.

- Never cut off the plug and hard wire into a fixed fused spur.
- The heater must not be located immediately below a mains socket outlet.
- Do NOT cover the heater as this may lead to a fire risk.
- Do NOT obstruct any any of the openings of the heater.
- Do NOT insert any object through any openings on the heater.
- Check the heater from time to time for accumulated dust.



- When not being used, please unplug the heater from the mains socket.
- Keep the mains lead away from the hot body of the heater and ensure that it is not pulled tight between the socket and the heater.
- Always unplug the heater and allow it to cool before moving it from one location to another.
- WARNING! This products must be installed correctly, failure to do so may cause damage to your product and /or your surroundings.
- Do not attempt to dismantle or repair any parts of the heater. This should only be done by a qualified service agent.
- In the unlikely event the appliance develops a fault, stop using it immediately and seek advice from the service department.

Don't :

- Never leave children unsupervised in a room where the fire is ON and unguarded.
- Never obstruct or cover the fan outlet or force items into fire openings.
- Never install or use the fire anywhere where water is in use, i.e. bathrooms,kitchens, shower rooms, and swimming pool etc.
- Never use aerosols or steam cleaners on or around the fire.

Note: When the fire is turned on for the first timer or when it has not been used for some time, it may release a slight,harmless odour. This odour is a normal occurrence caused by the initial heating of the internal heating elements or dust, and will disappear with use.

SAFETY CUT-OUT SYSTEM

- Never route the mains supply cable under carpet etc.
- Never install the fire close to curtains or combustible materials.
- Never use the fire to dry clothes etc.
- Never sit or stand on the fire.
- Never cut the off the plug and hard wire into a fixed fused spur.

Note: Any new wiring required must be in accordance with local and national codes and other applicable regulations in order to reduce the risk of the fire, electric shock, or other injuries.

WARNING!

Please do not obstruct the air vents of the electric fire.

This appliance has a 'self resetting' safety cut out system. This will activate if the air inlets or outlets are obstructed. If the electric fire is obstructed, it will overheat. If the temperature exceeds 85°C, the heater element will cut out, until a safe temperature is regained.

TROUBLE SHOOTING

Safety Cut-Out device:

To ensure against the potential hazard caused by blockage of the air outlet, this unit is equipped with an automatic over-temperature safety cut-out device. When the device is activated the heater will not operate. If this occurs, the unit can be reset using the following procedure.

1. Turn off the fire off by pressing the on/off switch in the unit.
2. Unplug the power cord from the electrical mains supply socket and leave it disconnected for at least 10 minutes.
3. Ensure that the air vents are free from obstruction.
4. Plug the power cord back in to the mains socket.
5. Turn the fire back on.
6. If the fire fails to operate, check the fuse in the plug.
7. If the fuse in the plug is OK and the fire is still not functioning, contact a qualified service person.

Problem	Potential cause	Corrective action
The fire won't turn on.	<p>Mains plug is not plugged in.</p> <p>The On/Off switch hasn't been switched on.</p> <p>The fuse in the plug has brown.</p>	<p>Check the mains socket to ensure the plug has been inserted correctly. Switch on using the operation switches.</p> <p>Check and change the fuse in the plug.</p>
No heat.	One or both of the heat selector switches haven't been switched on.	Ensure that the heat selection switches have been correctly switched on.
Heater operates and then the heat cuts out.	The safety cut-out may have operated.	Follow the procedure as outlined in the "safety cut-out device" section.

CLEANING AND CARE

- Unplug the appliance and allow the unit to cool down completely before cleaning.
- There are no specific requirements for the care of this unit, other than general cleaning.
- Brushed stainless steel (silver) fires can be cleaned using a cloth and a propriety cleaner. Other features (non-silver) can be cleaned using a damp cloth.
- If the supply cord is damaged, it must be replaced by a suitably qualified person.
- The area around the fire should be kept free from animal hair, lint and other extraneous material that may be drawn into the workings of the appliance which could affect its performance.

WARNING:

**DO NOT IMMERSE ANY PART OF THE
APPLIANCE IN WATER**

There are no internal user serviceable parts.

Check the regularly security of wall fixings as appropriate. Also check security of supply cable and connections. If the supply cable becomes damaged, it must be replaced by a service agent or competent person, such as a qualified electrician.

Should the fuse require replacing, it must be replaced with a fuse rated at 13 Amp and approved to BS1362. In the event of the mains plug being removed / replaced for any reason, please note: **IMPORTANT:** The wires in the mains lead are colored in accordance with the following code:

Blue - Neutral

Brown - Live

Green / Yellow -Earth

As the colors of the wires in the mains lead of this appliance may not correspond with the color markings identifying the terminals in your plug, proceed as follows.

The blue wire must be connected to the terminal marked with an N or colored black. The brown wire must be connected to the terminal marked with an L or colored red. The green /yellow wire must be connected to the earth terminal which is marked with an E or with the earth symbol.

WARNING: Never connect live or neutral wires to the earth terminal of the plug.

NOTE: If a moulded plug is fitted and has to be removed take great care in disposing of the plug and severed cable, it must be destroyed to prevent engaging into a socket.

Refer to Section 3.0 Appliance Data for fuse specification. Excluding fuses, use only genuine manufacturers spare parts available from your supplier.

Item	Symbol	Value	Unit	Item	Unit
Heat Output				Type of heat input for electric storage local space heaters only(select one)	
Nominal heat output	Pnom	2.0	KW	Manual heat charge control,with integrated thermostat	N/A
Nominal heat output (indicative)	Pmin	1.0	KW	Manual heat charge control with room and /or outdoor temperature feedback	N/A
Maximum continuous heat output	Pmax,c	2.0	KW	Electronic heat charge control with room and /or outdoor temperature feedback	N/A
Auxiliary electricity consumption				Fan assisted heat output	N/A
At nominal heat output	elmax	1.860	KW	Type of heat output/room temperature control(select one)	
At minimum heat output	elmin	0.948	KW	Single stage heat output an no room temperature control	N/A
In standby mode	elSB	N/A	KW	Two or more manual stage,no room temperature control	N/A
				With mechanic thermostat room temperature control	[yes]
				With electronic room temperature	N/A

				Electronic room temperature control plus day timer	N/A
				Electronic room temperature control plus week timer	N/A
				Other control options (multiple selections possible)	
				Room temperature control,with presence detection	N/A
				Room temperature control,with open window detection	N/A
				With distance control option	N/A
				With adaptive start control	N/A
				With working time limitation	N/A
				With black bulb sensor	N/A